



DIRENZA
PROVEN PERFORMANCE

Ford Fiesta MK8 1.0 Air Induction Kit Installation Guide

The Direnza Fiesta 1.0 Ecoboost Air Kit is a high performance, aftermarket Induction System offering increased airflow and performance over the stock setup. The extra air capacity provides the engine with more oxygen resulting in power gains and a great induction noise.

DISCLAIMER

- Allow the vehicle to cool completely prior to installation.
- We recommend that the Induction Kit is installed by a professional.
- Direnza is not responsible for any vehicle damage or personal injury due to installation errors, misuse or removal of Direnza products.

TOOLS REQUIRED

- Philips Screwdriver
- Flathead Screwdriver
- 7mm Socket
- 10mm Socket
- 4mm Allen Key

1x Air Filter
1x Metal Airbox
1x Airbox edging trim
1x Large Airbox edging trim
4x Bolts
4x Washers

1x O ring
2x Bobbins
1x Hard induction pipe
1x Bracket
1x 90° Silicone
3x Jubilee clips





1. Open the bonnet.




2. Undo jubilee clip connecting the induction hose to the throttle body..



3. Remove clip from underneath the intake pipe.



4. Unplug temp sensor.



5. Step 4 continued.



6. Undo screw securing the air snorkel to the slam panel, this allows some movement to remove the factory airbox.



7. Separate the snorkel from the airbox.



8. Remove intake pipe from the throttle body.



9. Step 8 continued.



10. The airbox assembly can now be removed.



11. The Direnza box sits on the factory mounting points.



12. Remove sensor from factory airbox.



13. Step 12 continued.



14. Insert this sensor into the Direnza hard pipe.



15. Insert screws through the holes in the bottom of the box.



16. The mounting bobbins can then be installed by threading them onto the screws.



17. Hold the bobbins and tighten from the top.



18. You can also fit the edging trim around the box and inside the exit hole for the hardpipe before installing.



19. Install the Direnza box into position.




20. Ensure the rubber O ring is properly inserted into the box and mounting point.



21. Install the 90° silicone and nip tight with jubilee clip to allow for some slight movement.



22. Remove upper nut on the vacuum pump to allow the Direnza support bracket to be mounted behind.




23. Remove lower nut on the vacuum pump to allow the Direnza support bracket to be mounted behind.




24. The Direnza support bracket sits behind the vacuum pump in this orientation.



25. Step 24 continued.



26. Fit and install 2x nuts to secure the vacuum pump. and support bracket.



27. Remove the vacuum pump line.



28. Install second jubilee clip on the 90° silicone.



29. Before installing the hard pipe remember to plug in the MAF sensor as this sits underneath.



30. You can now install the hardpipe, insert through the Airbox and then into the silicone joiner.




31. Re-secure the slam panel snorkel.



32. Install the Air Filter and jubilee clip.



33. Step 31 continued.



34. Line up the hardpipe and support bracket and secure together using supplied hardware.



35. Step 33 continued.



36. Re-install the vacuum pump line.



37. Secure the hardpipe in the 90° silicone by tightening the jubilee clip.



38. Re fit pipe into the clip on the air snorkel.



39. Fully secure the Air filter to the hard pipe by tightening the jubilee lip.



40. Double check all jubilee clips and ensure everything is tight.



39. Your Air Induction Kit is now installed.



40. Enjoy!



THANKS FOR YOUR ORDER!

We really appreciate you choosing Direnza Performance for your recent purchase.

We are always looking to feature your cars on our Social Media. **Tag and follow** us so we can keep the community growing! **@DIRENZAPERFORMANCE**

#DIRENZA #DIRENZAPERFORMANCE

