



DIRENZA
PROVEN PERFORMANCE

Ford Focus ST250 Air Induction Kit Installation Guide

The Direnza Ford Focus ST250 Cold Air Kit is a high performance, after-market induction system. Offering increased airflow and performance over the stock air filter setup. The extra air capacity provides the engine with more oxygen resulting in power gains and a great induction noise.

DISCLAIMER

- Allow the vehicle to cool completely prior to installation.
- We recommend that the Air Kit is installed by a professional.
- Direnza is not responsible for any vehicle damage or personal injury due to installation errors, misuse or removal of Direnza products.

TOOLS REQUIRED

- 4mm Allen Key
- Flathead Screwdriver
- 10mm Socket
- 8mm Socket
- Ratchet
- Extension

1x Air Filter
1x Heatshield
1x Silicone
3x Jubilee Clamps
2x Bobbins
2x Brackets

9x Washers
9x Allen Head Bolts
2x Nuts
1x 4mm Allen Key





1. Lift the bonnet.



2. Unplug the MAF sensor.



3. Remove the bolt on the MAF sensor using an 8mm socket.



4. You can now remove the plastic intake pipe.



5. Step 4 continued.



6. You can now remove the plastic slam panel scoop.



7. Step 6 continued.



8. Undo the jubilee clips on the OEM intake hose.



9. Step 8 continued.



10. The intake pipe can now be removed.



11. Step 11 continued.



12. The factory airbox and filter can also be removed. This can be done by firmly lifting from underneath the box.



13. The Direnza heat shield fits into the factory mounting points.



14. Step 13 continued.



15. Before installing the Direnza shield, you will need to install all the bobbins included with the Kit.



16. The second bobbin is fitted in this mounting bracket.



17. This bracket can then be fitted to the heat shield as pictured, using supplied hardware.



18. Step 17 continued.



19. Install the second mounting bracket.



20. Place the Direnza heat shield in to position in the engine bay.



21. Secure by pushing down on the bobbin mounting points.



22. You will need install a nut, washer and bolt to secure this part of the mounting bracket to the car.



23. Step 22 continue.



24. Re-install the slam panel scoop.



25. Install 2x jubilee clips around the supplied silicone joiner and fit onto OEM intake.



26. You can now install the aluminium intake pipe.



27. Tighten the jubilee clips to secure the silicone.



28. You can now install the filter.



29. Step 28 continued.



30. Tighten the jubilee clip to secure the Air Filter to the hard pipe.



31. Remember to re-install the OEM MAF sensor.



32. Using a 4mm allen key, install the MAF sensor.



33. Plug in MAF sensor.



34. Your Direnza Performance Cold Air Induction Kit is now installed.



You may also like...



Ford Focus MK3 ST250
MVT Intercooler.



Ford Focus MK3 ST250
RS Short Shifter.

THANKS FOR YOUR ORDER!

We really appreciate you choosing Direnza Performance for your recent purchase.

We are always looking to feature your cars on our Social Media. As a result, we are asking you to **tag and follow** us so we can keep the community growing! **@DIRENZAPERFORMANCE**

#DIRENZA #DIRENZAPERFORMANCE

